



GPS Location Finder Watch



3-Locate's GPS Location Finder Watch is 4 products in 1. The device is a GPS Receiver, Data Logger, Photo Tagger and a cutting edge analog watch.

The GPS Location Finder Watch has 8 LEDs to indicate the direction you must follow in order to return to the original location. To save a location just press the button for two seconds to save the location's coordinates. When you are walking back the 360 degree directional lights on the watch will tell you which direction you should be walking. And then, when you come within 50 meters of the saved location, the arrows around the watch face will begin flashing red, when you are within 15 meters the arrows will turn blue. This watch is great for anyone who needs help finding their way back to their car, hotel, or camping site.

You can also use the watch's data logger function to record all the GPS data. When you get home, connect the watch to your computer and use the included iTravel Data Logger software to view all your logged paths right on Google Maps or Google Earth.

\$149 plus S&H

www.3locate.com

Phone: 817-886-6861

email: info@3locate.com



GPS Location Finder Watch



- ✓ Simple to use
- ✓ Stylish analog watch
- ✓ Water resistant
- ✓ Never get lost again
- ✓ Red arrows will flash within 50 meters of the starting point
- ✓ Just follow the arrows to find your way back to the starting point
- ✓ Use it as a data logger to Record where you have been
- ✓ Use it as a photo tagger
- ✓ Blue arrows will flash within 15 meters of the starting point